

GENERAL INSTRUCTIONS FOR ASSEMBLING NAVY PATROL BOMBER NO. C8

This kit contains all parts for making an authentic scale model 1/10"—1'. Compare all parts with those shown in full size on drawing before starting to assemble.

Follow the instructions carefully and you will have a better finished model.

GLUE

Mix only a small quantity of glue at a time. It is not necessary to use clamps when assembling StromBecker Models.

SANDING

Glue the coarse sandpaper to one end of the 1/8" x1" x5" piece of wood so it can be used as a file. Use this in sanding parts to the right shape.

Before starting to assemble sand the fuselage all over and shape where necessary as shown on drawing.

Additional sanding will be necessary as you build up the model as shown on drawing. Be sure and sand off any excess glue. Where much sanding is required use the coarse sandpaper first and always finish off

with the fine sandpaper for a good smooth model.

FINISH

Many model makers prefer to finish their models in a natural wood finish using either shellac or clear lacquer. If you wish to paint your model in the regular colors you may do so. Use aluminum paint except on the bottom of the fuselage and wing-tip floats. These are to be painted black. See picture on carton.

For a good finish apply two coats of paint. Sand lightly with worn sandpaper between first and second coat. Put insignia on last.

You can also show ailerons, elevators, etc., by drawing these with pen and ink. Use only India drawing ink as other inks may rub off. See drawing.

C10 AIRPLANE STAND

Give your models a more realistic appearance by mounting them on one of these stands. Consists of streamlined base, and rod with flexible tip as shown at right. You can buy these stands wherever StromBecker Model Kits are sold and the price is 10c.

